How to Connect the GRP261X to your Wi-Fi



Please follow these steps to connect your Desk Phone to your Wi-Fi.
You can refer to this image to see the buttons.

(1) Push the **Menu/OK** button to active the **Menu**.
(2) Using right arrow and navigate to **System**, push **Menu/OK** button to select.
(3) Using down arrow and navigate to **Wi-Fi Settings**, push **Menu/OK** button to select.
(4) Using left/right arrows to Enable **Wi-Fi**.
(5) Using down arrow and navigate to **Scan** available Wi-Fi Networks.
(6) Select your **Wi-Fi** and select **Connect**, enter password.

Your Desk Phone will now connect to your Wi-Fi.

© 2024 MaxoTech Pty Ltd ABN 20159147430. All rights reserved.